

Oasis Dining Table Assembly | User Guide



Two people required for safe assembly


Opening Boxes: DO NOT use a knife to open the packaging as you may damage your furniture. Peel-off the tape, then lift and separate the cardboard flaps to open.

Please follow these Assembly | User Guide Instructions


Product Care

1


Oasis Low Round Dining Table 1195
Oasis Round Dining Table 1195




Oasis Oval Dining Table 1900
Oasis Oval Dining Table 2400




2



3



4



5

